

Suitable for work-piece which is easy to be deformed and wrinkled

Vacuum Pad Flat Series

Wide selection of pad sizes, materials and holder types.

Groove on a flat pad reduces deformation and wrinkle on a work-piece.



A piece of sheet sucked with Vacuum pad Ultrathin series



A piece of sheet sucked with Vacuum pad Flat series

Stroke length of a spring holder is selectable.

- Conventional long stroke holder (with cover) is integrated into VPC or VPD. Stroke : 6, 10, 15 and 20 mm
- Conventional long stroke holder (without cover) is renewed as VPOC or VPOD. Stroke : 20, 30, 40 and 50mm

Variety of selections in pad holder for "Copper alloy free" and against "low ozone concentration".


-S3 spec. : No copper based metal parts. HNBR or FKM is adopted for seal rubber.

A Vacuum Pad Series

Vacuum Pad Flat Series


Selection	list					
Pad type	Flat					
	Thin work-piece such	as sheet or plastic bag				
Recommended work-piece						
Pad size	5 sizes ø10, ø15, ø20, ø25, ø30mm					
Pad material		/, ø25, ø30mm /pes				
r uu materiai		Fluoro rubber, Conductive NBR (Low resistance),				
Holder size	Mini	Standard				
Holder type	4 types	7 types				
Fixed type	A					
Spring type		Holder without cover is available.				
Direct mount (Fixed type or Spring type)						






% 1.The material of Conductive NBR (low resistance) is a nitrile rubber (Volume resistance : 200 Ω ·cm or less)


% 2.Pad material N and NE are not suitable for use under ozone environment.



Vacuum Pad dimensions







Unit: mm

Model code	Pad O.D. ød		Connection configuration code
VP10F5-M49	10	5.6	-M4
VP15F5-M49	15	5.6	-1014
VP20F5-M69	20	8.6	
VP25F5-M69	25	8.6	-M6
VP30F5-M69	30	8.6	

%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

* 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts).




Pad screw Model code	М				øP1	øP2	Hex. Hex.	Weight (g)	Applicable pad model code
FVPLF15-M49	M4×0.7	3.9	14	10.1	7	9	10	5	VP10, 15F5
FVPLF30-M69	M6×1	5.4	18.5	13.1	13	17	17	22	VP20~30F5

. 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts).

Table of Connection configuration code, etc. for connection of pad and holder

Pad dia.	Model code	Connecti	on tuno	Connection	Model code of	Table of complement parts model code
(mm)	of pad rubber	Connecti	Connection type		Pad & screw set	Pad screw
ø10	VP10F5			-M4	VP10F5-M49	FVPLF15-M49
ø15	VP15F5	Screw type	(L)	-1014	VP15F5-M49	
ø20	VP20F5	(Connection with			VP20F5-M69	
ø25	VP25F5	screw)	ા મુખ્યત્	-M6	VP25F5-M69	FVPLF30-M69
ø30	VP30F5				VP30F5-M69	



2.Pad size

Code	10	15	20	25	30
Size (mm)	ø10	ø15	ø20	ø25	ø30
Connection config. code	-N	14		-M6	

③.Stroke (No code entry for Holder code : MA, A, MB, B and F)

ode	-4	-6	-10	-15	-20	-30	-40	-50
ke (mm)	4	6	10	15	20	30	40	50
VPMC	○(-M4, -M6)							
VPC		(-M4, -M6)	(-M4, -M6)	(-M4, -M6)	○(-M4, -M6)			
VPOC					○(- M6)	(-M6)	(-M6)	(-M6)
VPMD	(-M4, -M6)							
VPD		○(-M4, -M6)	○(-M4, -M6)	○(-M4, -M6)	○(-M4, -M6)			
VPOD					(-M6)	(-M6)	(-M6)	(-M6)
	ke (mm) VPMC VPC VPOC VPMD VPD	ke (mm) 4 VPMC (-M4, -M6) VPC VPDC VPMD (-M4, -M6) VPD	ke (mm) 4 6 VPMC (-M4, -M6) VPC (-M4, -M6) VPOC VPMD (-M4, -M6) VPD (-M4, -M6)	ke (mm) 4 6 10 VPMC (-M4, -M6) VPC (-M4, -M6) (-M4, -M6) VPOC VPMD (-M4, -M6) VPD (-M4, -M6)	ke (mm) 4 6 10 15 VPMC (-M4, -M6) VPC (-M4, -M6) (-M4, -M6) (-M4, -M6) VPOC VPD (-M4, -M6) (-M4, -M6) VPD (-M4, -M6) (-M4, -M6) (-M4, -M6)	ke (mm) 4 6 10 15 20 VPMC (-M4, -M6)	ke (mm) 4 6 10 15 20 30 VPMC (-M4, -M6) (-M4, -M6) (-M4, -M6) (-M4, -M6) VPC (-M4, -M6) (-M4, -M6) (-M4, -M6) (-M4, -M6) VPOC (-M4, -M6) (-M4, -M6) (-M6) (-M6) VPD (-M4, -M6) (-M4, -M6) (-M4, -M6) (-M4, -M6)	ke (mm) 4 6 10 15 20 30 40 VPMC (-M4, -M6)

% .Code in (): Connection configuration code.

④.Pad type

Code	F
Туре	Flat



⑤.Pad material / Application

Code	N	S	U	F	NE	SE
Rubber material	Nitrile rubber	Silicone rubber	Urethane rubber	Fluoro rubber	Conductive NBR (Low resistance)	Conductive silicone
Application	Cardboard	Semiconductors	Cardboard	Chemical	Semiconductors	Semiconductors
	Plywood	Taking out	Plywood	environment		Taking out
	Iron plate	molded parts	Iron plate	High temp.		molded parts
	Food-related	Thin workpieces		work-pieces		Thin work-
	Other general	Food-related				pieces
	work-pieces					
Color	Black	Natural (Ivory)	Blue	Gray	Black	Black

% 1.The material of Conductive NBR (low resistance) is a nitrile rubber (Volume resistance : 200 $\Omega\cdot$ cm or less)

* 2.Pad material N and NE are not suitable for use under ozone environment.

6.Port size and joint type

Joi	nt type		Push-in fitting (mm)					Barb fitting (mm)			Female thread	
С	ode	-180J	-2J	-3J	-4J	-6J	-3B	-4B	-6B	-M5	-M6	
	Size	ø1.8	ø2	ø3	ø4	ø6	ø3×ø2	ø4×ø2.5	ø6×ø4	M5×0.8	M6×1	
Dimedia	-M4	0	0	0	0	0	0	0	0	0	0	
, aufi care	-M6	0	0	0	0	0	0	0	0	0	0	

%.Joint size differs depending on the holder type. Check the joint size by the holder dimensions lists in following pages.

⑦.Free holder or Fall prevention valve (Option)

Code	FH	FHH	ECV
Option	Free holder articulation angle : 30°	Free holder articulation angle : 15°	Fall prevention valve

⑧.Filter (Option)

Code	F15	F30
Pad dia. (mm)	ø10 ~ ø30mm	ø20 ~ ø30mm

% . Recommended pad size for F15 : ø10 \sim ø25mm

9.-S3 spec.


Code	No code	-S3
Cree	Standard	Metal parts material : Copper alloy free material
Spec.	Standard	Sealing parts material : FKM or HNBR

*. Free holder, Fall prevention valve and Filter are not available when "-S3" is selected.

Vacuum pad + Fixed type holder Dimensions

VPMA Fixed type / Top port / Push-in fitting / Mini holder

RoHS Compliant X Copper alloy free available of CAD (2D&3D)



.5 : Replaced with Pad rubber material code. Refer to page 916 for details.


※ .9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts). -S3 spec. is available for model codes with 9 in the table above.

※.Pad material N and NE are not suitable for use under ozone environment.

※.Tightening torque of a pad holder fixing bulkhead nut is as followings. Thread size : M8×0.75 ▶ 2.5~3.5N·m. Thread size : M10×1 ▶ 5~7N·m.

VPMA Fixed type / Top port / Barb fitting / Mini holder

RoHS Compliant X Copper alloy free available M CAD (2D&3D)



Model code	Pad O.D. ød	Tube I.D. øD	В	С	Connection config. code	
VPMA10F5-3B9	10	2	31.4	6		
VPMA10F5-4B9	10	2.5	32.4	7	-M4	
VPMA15F5-3B9	15	2	31.4	6	-1014	
VPMA15F5-4B9	15	2.5	32.4	7		
VPMA20F5-4B9	20	2.5	_	_	-M6	
VPMA20F5-6B9	20	4				
VPMA25F5-4B9	25	2.5	_	_		
VPMA25F5-6B9	20	4				
VPMA30F5-4B9	30	2.5	_	_		
VPMA30F5-6B9	30	4		_		

*.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

* 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts).

* .Pad material N and NE are not suitable for use under ozone environment.


※.Tightening torque of a pad holder fixing bulkhead nut is as followings. Thread size : M6×0.75 ▶ 2~3N·m. Thread size : M10×1 ▶ 5~7N·m.






VPA Fixed type / Top port / Push-in fitting / Standard holder

RoHS Compliant X Copper alloy free available 🚿 CAD (2D&3D)





Unit	• •	mm
Unit		THE

Model code	Pad O.D. ød	Tube O.D. øD	Thread M	В	L	Tube end C	Hex. H1	Hex. H2	Connection config. code
		ØD	IVI		1	C		112	Conny. Code
VPA10F5-6J9	10	_	-	-	-	-	-	-	-M4
VPA15F5-6J9	15	-	-	-	-	-	-	-	-1014
VPA20F5-3J		3	M12×1	51	20.3	10.9	14	12	
VPA20F5-4J9	20	4		51	20.3	10.9	14	12	
VPA20F5-6J9		6	M14×1	42	19.9	11.7	17	14	1
VPA25F5-3J		3	M12×1	51	20.3	10.9	14	12]
VPA25F5-4J9	25	4	10112 * 1	51	20.3	10.9	14	12	-M6
VPA25F5-6J9		6	M14×1	42	19.9	11.7	17	14	
VPA30F5-3J		3	M12×1	51	20.3	10.9	14	12]
VPA30F5-4J9	30	4	10112*1	51	20.3	10.9	14	12	
VPA30F5-6J9		6	M14×1	42	19.9	11.7	17	14	

*.5 : Replaced with Pad rubber material code. Refer to page 916 for details.


* 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts). -S3 spec. is available for model codes with 9 in the table above.

% .Pad material N and NE are not suitable for use under ozone environment.

. Tightening torque of a pad holder fixing bulkhead nut is as followings. Pad O.D. : ø10, ø15mm ▶ 12~14N·m.Pad O.D. : ø20~ø30mm ▶ 18~21N·m.

VPA Fixed type / Top port / Barb fitting / Standard holder

RoHS Compliant X Copper alloy free available 🚿 CAD (2D&3D)



Unit:mm

Model code	Pad O.D. ød	Tube I.D. øD	Connection config. code
VPA10F5-6B9	10	—	-M4
VPA15F5-6B9	15	—	-1014
VPA20F5-4B9	20	2.5	
VPA20F5-6B9	20	4	
VPA25F5-4B9	25	2.5	-M6
VPA25F5-6B9	25	4	-1010
VPA30F5-4B9	30	2.5	
VPA30F5-6B9	30	4	

*.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

* 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts).


* .Pad material N and NE are not suitable for use under ozone environment.

※.Tightening torque of a pad holder fixing bulkhead nut is as followings. Pad O.D. : ø10, ø15mm ▶12~14N·m. Pad O.D. : ø20~ø30mm ▶18~21N·m.

VPA Fixed type / Top port / Female thread / Standard holder

RoHS Compliant 🐹 Copper alloy free available 🚿 CAD (2D&3D)





Unit: mm

Model code	Pad O.D. ød	Connection config. code
VPA20F5-M69	20	
VPA25F5-M69	25	-M6
VPA30F5-M69	30	

%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

* 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts).


% .Pad material N and NE are not suitable for use under ozone environment.

※.Tightening torque of a pad holder fixing bulkhead nut is as followings. Pad O.D. : ø10, ø15mm ▶12~14N·m. Pad O.D. : ø20~ø30mm ▶18~21N·m.



VPMB Fixed type / Side port / Push-in fitting / Mini holder

RoHS Compliant X Copper alloy free available M CAD (2D&3D)



	Pad O.D.	Tube O.D.		Tube end	Connection config.
Model code		øD		С	code
VPMB10F5-180J		1.8	40.7	0.4	
VPMB10F5-2J		2	13.7	8.4	
VPMB10F5-3J	10	3	17.5	10.9	
VPMB10F5-4J9		4	6.17	10.9	
VPMB10F5-6J9		6	19.4	11.7	-M4
VPMB15F5-180J		1.8	13.7	8.4	-1014
VPMB15F5-2J		2	13.7	0.4	
VPMB15F5-3J	15	3	17.5	10.9	
VPMB15F5-4J9	[4	17.5	10.9	
VPMB15F5-6J9		6	19.4	11.7	
VPMB20F5-180J	-	1.8	13.7	8.4	
VPMB20F5-2J		2			-
VPMB20F5-3J	20	3	17.5	10.9	
VPMB20F5-4J9		4			
VPMB20F5-6J9		6	19.4	11.7	
VPMB25F5-180J		1.8	13.7	8.4	
VPMB25F5-2J		2			
VPMB25F5-3J	25	3	17.5	10.9	-M6
VPMB25F5-4J9		4			
VPMB25F5-6J9		6	19.4	11.7	
VPMB30F5-180J	-	1.8	13.7	8.4	
VPMB30F5-2J		2	-	-	
VPMB30F5-3J	30	3	17.5	10.9	
VPMB30F5-4J9		4			
VPMB30F5-6J9		6	19.4	11.7	


%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

※. 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts). -S3 spec. is available for model codes with 9 in the table above.

* .Pad material N and NE are not suitable for use under ozone environment.

VPMB Fixed type / Side port / Barb fitting / Mini holder

RoHS Compliant X Copper alloy free available 🚿 CAD (2D&3D)



Unit : mm

Model code	Tube I.D. øD	Pad O.D. ød	E	С	Connection config. code
VPMB10F5-3B9	2		13.4	6	
VPMB10F5-4B9	2.5	10	14.9	7	
VPMB10F5-6B9	4		14.9	1	-M4
VPMB15F5-3B9	2		13.4	6	-1014
VPMB15F5-4B9	2.5	15	14.9	7	
VPMB15F5-6B9	4		14.9		
VPMB20F5-3B9	2		13.4	6	
VPMB20F5-4B9	2.5	20	14.9	7	
VPMB20F5-6B9	4		14.9	1	
VPMB25F5-3B9	2		13.4	6	
VPMB25F5-4B9	2.5	25	14.9	7	-M6
VPMB25F5-6B9	4		14.9	1	
VPMB30F5-3B9	2		13.4	6	
VPMB30F5-4B9	2.5	30	14.9	7]
VPMB30F5-6B9	4		14.9		


%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

* 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts).

* .Pad material N and NE are not suitable for use under ozone environment.

VPMB Fixed type / Side port / Female thread / Mini holder

RoHS Compliant X Copper alloy free available of CAD (2D&3D)



Model code	Pad O.D. ød	Connection config. code
VPMB10F5-M59	10	-M4
VPMB15F5-M59	15	-1014
VPMB20F5-M59	20	
VPMB25F5-M59	25	-M6
VPMB30F5-M59	30	

%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

* 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts).


* .Pad material N and NE are not suitable for use under ozone environment.



Unit: mm

VPB Fixed type / Side port / Push-in fitting / Standard holder

RoHS Compliant X Copper alloy free available M CAD (2D&3D)



					Unit + Initi
Model code	Pad O.D.	Tube O.D.	E	Tube end	Connection config.
	ød	øD		С	code
VPB10F5-3J		3	18.6	10.9	
VPB10F5-4J9	10	4	10.0	10.9	
VPB10F5-6J9		6	19.9	11.7	-M4
VPB15F5-3J		3	18.6	10.9	-1014
VPB15F5-4J9	15	4	10.0	10.9	1
VPB15F5-6J9		6	19.9	11.7	
VPB20F5-3J		3	18.6	10.9	
VPB20F5-4J9	20	4	16.0	10.9	
VPB20F5-6J9		6	19.9	11.7	
VPB25F5-3J		3	18.6	10.9	
VPB25F5-4J9	25	4	10.0	10.9	-M6
VPB25F5-6J9		6	19.9	11.7	
VPB30F5-3J		3	18.6	10.9	
VPB30F5-4J9	30	4	10.0	10.9	
VPB30F5-6J9		6	19.9	11.7	


%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

※ 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts). -S3 spec. is available for model codes with 9 in the table above.

% .Pad material N and NE are not suitable for use under ozone environment.

VPB Fixed type / Side port / Barb fitting / Standard holder

RoHS Compliant X Copper alloy free available 🚿 CAD (2D&3D)



Unit : mm

Model code	Pad O.D. ød	Tube I.D. øD	Connection config. code
VPB10F5-4B9	10	2.5	
VPB10F5-6B9	10	4	-M4
VPB15F5-4B9	15	2.5	-1014
VPB15F5-6B9	15	4	
VPB20F5-4B9	20	2.5	
VPB20F5-6B9	20	4	
VPB25F5-4B9	25	2.5	-M6
VPB25F5-6B9	25	4	-1010
VPB30F5-4B9	30	2.5	
VPB30F5-6B9	30	4	

VPB30F5-M69


%.5: Replaced with Pad rubber material code. Refer to page 916 for details.

* 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts).

% .Pad material N and NE are not suitable for use under ozone environment.

VPB Fixed type / Side port / Female thread / Standard holder

RoHS Compliant X Copper alloy free available of CAD (2D&3D)



%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

30

. 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts).


* .Pad material N and NE are not suitable for use under ozone environment.



Vacuum pad + Spring type holder Dimensions

VPMC Spring type / Top port / Push-in fitting / Mini holder

RoHS Compliant X Copper alloy free available of CAD (2D&3D)



Unit:mm


Model code	Pad O.D.	Tube O.D.	В	Tube end	Spring force	Connection
		øD		С	(N)	config. code
VPMC10-4F5-180J		1.8	42.3	<u>.</u>		
VPMC10-4F5-2J	10	2	42.3	8.4	1.0~1.3	
VPMC10-4F5-3J	10	3	46.1	10.9	1.0~ 1.3	
VPMC10-4F5-4J9		4	40.1	10.9		-M4
VPMC15-4F5-180J		1.8	42.3	8.4		-1/14
VPMC15-4F5-2J	15	2	42.5	0.4	1.0~1.3	
VPMC15-4F5-3J	15	3	3 46.1	10.9	1.0701.3	
VPMC15-4F5-4J9		4				
VPMC20-4F5-180J	20 -	1.8	53.2	8.4	- 1.0~1.3	
VPMC20-4F5-2J		2		0.4		
VPMC20-4F5-3J		3	57	10.9		
VPMC20-4F5-4J9		4				
VPMC25-4F5-180J		1.8	53.2	8.4	- 1.0~1.3	
VPMC25-4F5-2J	25	2	55.2	0.4		-M6
VPMC25-4F5-3J	25	3	57	10.9		-1010
VPMC25-4F5-4J9		4	57	10.9		
VPMC30-4F5-180J		1.8	53.2	8.4		
VPMC30-4F5-2J	30	2	53.2	ö.4	1.0~1.3	
VPMC30-4F5-3J	50	3	57	10.9	1.0 01.3	
VPMC30-4F5-4J9		4	3/	10.9		

%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

% .Pad material N and NE are not suitable for use under ozone environment.

VPMC Spring type / Top port / Barb fitting / Mini holder

RoHS Compliant X Copper alloy free available of CAD (2D&3D)



Model code	Pad O.D. ød	Tube I.D. øD	В	С	Spring force (N)	Connection config. code
VPMC10-4F5-3B9		2	42	6		
VPMC10-4F5-4B9	10	2.5	43.5	7	1.0~1.3	
VPMC10-4F5-6B9		4	43.5	1		-M4
VPMC15-4F5-3B9		2	42	6		-1014
VPMC15-4F5-4B9	15	2.5	43.5	7	1.0~1.3	
VPMC15-4F5-6B9		4	43.5 7			
VPMC20-4F5-3B9		2	52.9	6		
VPMC20-4F5-4B9	20	2.5	54.4	7	1.0~1.3	
VPMC20-4F5-6B9		4	54.4	/		
VPMC25-4F5-3B9		2	52.9	6		
VPMC25-4F5-4B9	25	2.5	E 4 . 4	7	1.0~1.3	-M6
VPMC25-4F5-6B9		4	54.4	1		
VPMC30-4F5-3B9		2	52.9	6		
VPMC30-4F5-4B9	30	2.5	E4 4	7	1.0~1.3	
VPMC30-4F5-6B9		4	54.4	/		

%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

. 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts).

* .Pad material N and NE are not suitable for use under ozone environment.




Stroke (mm)

6,10,15,20

VPC Spring type / Top port / Push-in fitting / Standard holder

RoHS Compliant 🕱 Copper alloy free available 🛷 CAD (2D&3D)





Unit:mm

Model code	Pad O.D.	Tube O.D.	В	L1	L2	Tube end	Stroke	Spring force	Connection
	ød	øD			LZ	С	S	(N)	config. code
VPC10-6F5-3J		3	62.1			10.9			
VPC10-6F5-4J9		4	02.1	29.4		10.9	6	4.0~7.1	
VPC10-6F5-6J9		6	63.5		20	11.7			
VPC10-10F5-3J		3	66.6		20	10.9			
VPC10-10F5-4J		4	00.0	33.9		10.5	10	2.0~5.2	
VPC10-10F5-6J	10	6	68			11.7			
VPC10-15F5-3J		3	76.6			10.9			
VPC10-15F5-4J		4	70.0	38.9	25	10.5	15	2.0~5.9	
VPC10-15F5-6J	-	6	78			11.7			
VPC10-20F5-3J		3	92.6			10.9			M4
VPC10-20F5-4J		4	52.0	45.9	34	10.5	20	1.1~4.8	
VPC10-20F5-6J		6	94			11.7			
VPC15-6F5-3J		3	62.1	29.4		10.9		4.0~7.1	
VPC15-6F5-4J9		4	02.1			10.5	6		
VPC15-6F5-6J9		6	63.5		20	11.7			
VPC15-10F5-3J		3	66.6		20	10.9			
VPC15-10F5-4J		4	00.0	33.9		10.0	10	2.0~5.2	
VPC15-10F5-6J	15	6	68			11.7			
VPC15-15F5-3J		3	76.6			10.9			
VPC15-15F5-4J	4 6 3 4	4	10.0	38.9	25	10.0	15	2.0~5.9	
VPC15-15F5-6J		6	78			11.7			
VPC15-20F5-3J		3	92.6			10.9			
VPC15-20F5-4J		4	52.0	45.9	34	10.9	20	1.1~4.8	
VPC15-20F5-6J		6	94			11.7			

%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.


※ [9]: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts). -S3 spec. is available for model codes with 9 in the table above.

% .Pad material N and NE are not suitable for use under ozone environment.

※.Tightening torque of a pad holder fixing bulkhead nut is as followings. Pad O.D. : ø10, ø15mm ▶8~10N·m.Pad O.D. : ø20~ø30mm ▶4.5~6N·m. RoHS Compliant X Copper alloy free available H CAD (2D&3D)







Unit : mm

Model code	Pad O.D. ød	Tube O.D. øD	В		L2	Tube end C	Stroke S	Spring force (N)	Connection config. code
VPC20-6F5-3J		3	65			10.9			
VPC20-6F5-4J9		4	60	32.3		10.9	6	7.0~12.6	
VPC20-6F5-6J9		6	66.4		20	11.7			
VPC20-10F5-3J		3	71		20	10.9			
VPC20-10F5-4J		4	71	38.3		10.5	10	3.3~10.0	
VPC20-10F5-6J	20	6	72.4			11.7			
VPC20-15F5-3J	20	3	81			10.9			
VPC20-15F5-4J		4	01	43.3	25	10.5	15	3.3~10.4	
VPC20-15F5-6J		6	82.4			11.7			
VPC20-20F5-3J		3	97			10.9			
VPC20-20F5-4J		4		50.3	34	10.0	20	2.0~8.7	
VPC20-20F5-6J		6	98.4			11.7			-M6
VPC25-6F5-3J		3	65	32.3		10.9		7.0~12.6	
VPC25-6F5-4J9	4	4					6		
VPC25-6F5-6J9		6	66.4		20	11.7			
VPC25-10F5-3J		3	71			10.9			
VPC25-10F5-4J		4		38.3			10	3.3~10.0	
VPC25-10F5-6J	25	6	72.4			11.7			
VPC25-15F5-3J		3	81			10.9			
VPC25-15F5-4J		4		43.3	25		15	3.3~10.4	-
VPC25-15F5-6J		6	82.4			11.7			
VPC25-20F5-3J		3	97			10.9			
VPC25-20F5-4J		4		50.3	34		20	2.0~8.7	
VPC25-20F5-6J		6	98.4			11.7			



Unit:mm

Model code	Pad O.D. ød	Tube O.D. øD	В	L1	L2	Tube end C	Stroke S	Spring force (N)	Connection config. code
VPC30-6F5-3J		3	65			10.9			
VPC30-6F5-4J9		4	05	32.3		10.9	6	7.0~12.6	
VPC30-6F5-6J9		6	66.4		20	11.7			
VPC30-10F5-3J		3	71		20	10.9			
VPC30-10F5-4J		4	/ 1	38.3		10.5	10	3.3~10.0	M6
VPC30-10F5-6J	30	6	72.4			11.7			
VPC30-15F5-3J	30	3	81			10.9			-1010
VPC30-15F5-4J		4	01	43.3	25	10.9	15	3.3~10.4	
VPC30-15F5-6J		6	82.4			11.7			_
VPC30-20F5-3J		3	07			10.9			
VPC30-20F5-4J]	4	97	50.3	34	10.9	20	2.0~8.7	
VPC30-20F5-6J		6	98.4			11.7			

%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.


* .9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts). -S3 spec. is available for model codes with 9 in the table above.

%.Pad material N and NE are not suitable for use under ozone environment.

※.Tightening torque of a pad holder fixing bulkhead nut is as followings. Pad O.D.: ø10, ø15mm ▶8~10N·m. Pad O.D.: ø20~ø30mm ▶4.5~6N·m.

VPC Spring type / Top port / Barb fitting / Standard holder

RoHS Compliant X Copper alloy free available H CAD (2D&3D)



Unit:mm

Model code	Pad O.D. ød	Tube I.D. øD	В	L1	L2	Stroke S	Spring force (N)	Connection config. code
VPC10-6F5-4B9		2.5	50.5	00.4		0	4.0~7.1	
VPC10-6F5-6B9		4	59.5	29.4	20	6	4.0~7.1	
VPC10-10F5-4B		2.5	64	33.9	20	10	2.0~5.2	
VPC10-10F5-6B	10	4	04	33.9		10	2.010 5.2	
VPC10-15F5-4B	10	2.5	74	38.9	25	15	2.0~5.9	
VPC10-15F5-6B		4	74	30.9	25	15	2.010 5.9	
VPC10-20F5-4B		2.5	90	45.9	34	20	1.1~4.8	
VPC10-20F5-6B]	4	30	43.5	34	20	1.1 - 4.0	-M4
VPC15-6F5-4B9		2.5	59.5	29.4		6	4.0~7.1	-1014
VPC15-6F5-6B9		4	55.5	20.4	20		4.0 7.1	
VPC15-10F5-4B		2.5	64	33.9	20	10	2.0~5.2	
VPC15-10F5-6B	15	4		00.0			2.0 0.2	
VPC15-15F5-4B		2.5	74	38.9	25	15	2.0~5.9	
VPC15-15F5-6B		4		00.0			2.0 0.0	
VPC15-20F5-4B		2.5	90	45.9	34	20	1.1~4.8	
VPC15-20F5-6B		4						
VPC20-6F5-4B9		2.5	62.4	32.3	20	6	7.0~12.6	
VPC20-6F5-6B9		4				-		
VPC20-10F5-4B		2.5	68.4	38.3		10	3.3~10.0	
VPC20-10F5-6B	20	4						
VPC20-15F5-4B		2.5	78.4	43.3	25	15	3.3~10.4	
VPC20-15F5-6B		4						
VPC20-20F5-4B		2.5	94.4	50.3	34	20	2.0~8.7	
VPC20-20F5-6B		4						-M6
VPC25-6F5-4B9		2.5	62.4	32.3		6	7.0~12.6	
VPC25-6F5-6B9		4			20			
VPC25-10F5-4B		2.5	68.4	38.3		10	3.3~10.0	
VPC25-10F5-6B	25	4						
VPC25-15F5-4B		2.5	78.4	43.3	25	15	3.3~10.4	
VPC25-15F5-6B		4						
VPC25-20F5-4B		2.5	94.4	50.3	34	20	2.0~8.7	
VPC25-20F5-6B		4						



Unit : mm

Model code	Pad O.D. ød	Tube I.D. øD	В	L1	L2	Stroke S	Spring force (N)	Connection config. code
VPC30-6F5-4B9		2.5	62.4	32.3		6	7.0~12.6	
VPC30-6F5-6B9		4	02.4	32.3	20		7.0**12.0	
VPC30-10F5-4B		2.5	68.4	38.3	20	10	3.3~10.0	
VPC30-10F5-6B	30	4	00.4	30.3		10	3.5 - 10.0	M6 -
VPC30-15F5-4B	30	2.5	- 78.4	43.3	25	15	3.3~10.4	
VPC30-15F5-6B		4		43.5				
VPC30-20F5-4B		2.5	- 94.4	50.3	34	20	2.0~8.7	
VPC30-20F5-6B		4	94.4	50.5	34	20	2.0~8.7	

%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.


* .9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts). -S3 spec. is available for model codes with 9 in the table above.

% .Pad material N and NE are not suitable for use under ozone environment.

※.Tightening torque of a pad holder fixing bulkhead nut is as followings. Pad O.D.: ø10, ø15mm ▶8~10N·m. Pad O.D.: ø20~ø30mm ▶4.5~6N·m.

VPC Spring type / Top port / Female thread / Standard holder

RoHS Compliant X Copper alloy free available of CAD (2D&3D)



Stroke (mm)

Model code	Pad O.D.	В	L1	L2		Spring force	Connection
						(N)	config. code
VPC10-6F5-M69		49.4	29.4	20	6	4.0~7.1	
VPC10-10F5-M6	10	53.9	33.9	20	10	2.0~5.2	
VPC10-15F5-M6	10	63.9	38.9	25	15	2.0~5.9	
VPC10-20F5-M6	15	79.9	45.9	34	20	1.1~4.8	-M4
VPC15-6F5-M69		49.4	29.4	20	6	4.0~7.1	-1/14
VPC15-10F5-M6		53.9	33.9	20	10	2.0~5.2	
VPC15-15F5-M6		63.9	38.9	25	15	2.0~5.9	
VPC15-20F5-M6		79.9	45.9	34	20	1.1~4.8	
VPC20-6F5-M69		52.3	32.3	20	6	7.0~12.6	
VPC20-10F5-M6	20	58.3	38.3	20	10	3.3~10.0	
VPC20-15F5-M6	20	68.3	43.3	25	15	3.3~10.4	
VPC20-20F5-M6		84.3	50.3	34	20	2.0~8.7	
VPC25-6F5-M69		52.3	32.3	20	6	7.0~12.6	
VPC25-10F5-M6	25	58.3	38.3	20	10	3.3~10.0	-M6
VPC25-15F5-M6	20	68.3	43.3	25	15	3.3~10.4	-1010
VPC25-20F5-M6		84.3	50.3	34	20	2.0~8.7	
VPC30-6F5-M69		52.3	32.3	20	6	7.0~12.6	
VPC30-10F5-M6	20	58.3	38.3	20	10	3.3~10.0	
VPC30-15F5-M6	30	68.3	43.3	25	15	3.3~10.4	
VPC30-20F5-M6		84.3	50.3	34	20	2.0~8.7	


%. 5 : Replaced with Pad rubber material code. Refer to page 916 for details.


* .9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts). -S3 spec. is available for model codes with 9 in the table above.

% .Pad material N and NE are not suitable for use under ozone environment.


. Tightening torque of a pad holder fixing bulkhead nut is as followings. Pad O.D. : ø10, ø15mm ▶8~10N·m. Pad O.D. : ø20~ø30mm ▶4.5~6N·m.














20,30,40,50

11	٠	
Unit	٠	mm

Model code	Pad O.D.	Tube I.D.	В	L	Stroke	Spring force	Connection					
		øD				(N)	config. code					
VPOC20-20F5-4B		2.5	71.4	52.3	20	1.5~4.9						
VPOC20-20F5-6B		4	71.4	52.5	20	1.5**4.9						
VPOC20-30F5-4B		2.5	84.4	65.3	30	1.1~4.8						
VPOC20-30F5-6B	20	4	04.4	05.5	30	1.1**4.0						
VPOC20-40F5-4B	20	2.5	97.4	78.3	40	1.0~4.5						
VPOC20-40F5-6B		4	97.4	76.5	40	1.0**4.5	-					
VPOC20-50F5-4B		2.5	110.4	91.3	50	0.9~4.5						
VPOC20-50F5-6B		4	110.4	91.5	50	0.9**4.5						
VPOC25-20F5-4B	25						2.5	71.4	52.3	20	1.5~4.9	
VPOC25-20F5-6B		4	/ 1.4	52.5	20	1.5**4.9	4					
VPOC25-30F5-4B				2.5	84.4	65.3	30	1.1~4.8				
VPOC25-30F5-6B		4		00.0	50	1.1 4.0	-M6					
VPOC25-40F5-4B	25	2.5	97.4	78.3	40	1.0~4.5	-1010					
VPOC25-40F5-6B		4	97.4	10.0	10	1.0 4.0	-					
VPOC25-50F5-4B		2.5	110.4	91.3	50	0.9~4.5						
VPOC25-50F5-6B		4	110.4	51.5		0.3 4.5						
VPOC30-20F5-4B		2.5	71.4	52.3	20	1.5~4.9						
VPOC30-20F5-6B		4	71.4	52.5	20	1.5 4.5						
VPOC30-30F5-4B		2.5	84.4	65.3	30	1.1~4.8						
VPOC30-30F5-6B	30	4	04.4	00.0		1.1 4.0						
VPOC30-40F5-4B	30	2.5	97.4	78.3	40	1.0~4.5						
VPOC30-40F5-6B		4	57.4	10.5	40	1.0 - 4.5	_					
VPOC30-50F5-4B		2.5	110.4	91.3	50	0.9~4.5						
VPOC30-50F5-6B		4	110.4	51.5	50	0.0 - 4.0						

*.5 : Replaced with Pad rubber material code. Refer to page 916 for details.





Spring force	Connection
(N)	config. code
1.5~4.9	


	ød				(N)	config. code
VPOC20-20F5-M6		61.3	52.3	20	1.5~4.9	
VPOC20-30F5-M6	20	74.3	65.3	30	1.1~4.8	
VPOC20-40F5-M6	20	87.3	78.3	40	1.0~4.5	
VPOC20-50F5-M6]	100.3	91.3	50	0.9~4.5	
VPOC25-20F5-M6		61.3	52.3	20	1.5~4.9	
VPOC25-30F5-M6	25	74.3	65.3	30	1.1~4.8	-M6
VPOC25-40F5-M6	25	87.3	78.3	40	1.0~4.5	-1010
VPOC25-50F5-M6		100.3	91.3	50	0.9~4.5	
VPOC30-20F5-M6		61.3	52.3	20	1.5~4.9	
VPOC30-30F5-M6	30	74.3	65.3	30	1.1~4.8	
VPOC30-40F5-M6		87.3	78.3	40	1.0~4.5	
VPOC30-50F5-M6		100.3	91.3	50	0.9~4.5	

%. 5 : Replaced with Pad rubber material code. Refer to page 916 for details.

% .Tightening torque of a pad holder fixing bulkhead nut is 4.5~6N m.

VPMD Spring type / Side port / Push-in fitting / Mini holder

RoHS Compliant 💥 Copper alloy free available 🛷 CAD (2D&3D)



Unit : mm

Stroke (mm)

Model code	Pad O.D.	Tube O.D.		Tube end	Spring force	Connection
Model code	ød	øD	_	С	(N)	config. code
VPMD10-4F5-180J		1.8	13.7	8.4		
VPMD10-4F5-2J		2	10.7	0.4	-	
VPMD10-4F5-3J	10	3	17.5	10.9	1.0~1.3	
VPMD10-4F5-4J9		4		10.0	_	-M4
VPMD10-4F5-6J9		6	19.4	11.7		
VPMD15-4F5-180J		1.8	13.7	8.4		111-
VPMD15-4F5-2J		2	10.7	0.4	_	
VPMD15-4F5-3J	15	3	17.5	10.9	1.0~1.3	
VPMD15-4F5-4J9		4	17.5	10.5	_	
VPMD15-4F5-6J9		6	19.4	11.7		
VPMD20-4F5-180J		1.8	13.7	8.4		
VPMD20-4F5-2J		2		0.4	_	
VPMD20-4F5-3J	20	3	17.5	10.9	1.0~1.3	
VPMD20-4F5-4J9		4		10.0	_	
VPMD20-4F5-6J9		6	19.4	11.7		
VPMD25-4F5-180J		1.8	13.7	8.4		
VPMD25-4F5-2J		2	10.7	0.4		
VPMD25-4F5-3J	25	3	17.5	10.9	1.0~1.3	-M6
VPMD25-4F5-4J9		4		10.0		
VPMD25-4F5-6J9		6	19.4	11.7		
VPMD30-4F5-180J		1.8	13.7	8.4		
VPMD30-4F5-2J		2	15.7	0.4		
VPMD30-4F5-3J	30	3	17.5	10.9	1.0~1.3	
VPMD30-4F5-4J9	Ľ	4	17.5	10.3		
VPMD30-4F5-6J9		6	19.4	11.7		

%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.


※.9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts). -S3 spec. is available for model codes with 9 in the table above.

* .Pad material N and NE are not suitable for use under ozone environment.



VPMD Spring type / Side port / Barb fitting / Mini holder

RoHS Compliant 💥 Copper alloy free available 🚿 CAD (2D&3D)



Unit : mm

Model code	Pad O.D. ød	Tube I.D. øD		С	Spring force (N)	Connection config. code
VPMD10-4F5-3B9		2	13.4	6		
VPMD10-4F5-4B9	10	2.5	14.9	7	1.0~1.3	
VPMD10-4F5-6B9		4	14.9	1		-M4
VPMD15-4F5-3B9		2	13.4	6		-1014
VPMD15-4F5-4B9	15	2.5	- 14.9	7	1.0~1.3	
VPMD15-4F5-6B9		4		1		
VPMD20-4F5-3B9		2	13.4	6	1.0~1.3	
VPMD20-4F5-4B9	20	2.5	14.9	7		
VPMD20-4F5-6B9		4	14.9	'		
VPMD25-4F5-3B9		2	13.4	6		
VPMD25-4F5-4B9	25	2.5	14.9	7	1.0~1.3	-M6
VPMD25-4F5-6B9		4	14.9	/		
VPMD30-4F5-3B9	30	2	13.4	6	1.0~1.3	
VPMD30-4F5-4B9		2.5	14.9	7		
VPMD30-4F5-6B9		4	14.9	1		


%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

* 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts).

* .Pad material N and NE are not suitable for use under ozone environment.

VPMD Spring type / Side port / Female thread / Mini holder

RoHS Compliant X Copper alloy free available M CAD (2D&3D)



	15	1.0 1.5	
VPMD20-4F5-M59	20	1.0~1.3	
VPMD25-4F5-M59	25	1.0~1.3	-M6
VPMD30-4F5-M59	30	1.0~1.3	

%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

. 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts).


* .Pad material N and NE are not suitable for use under ozone environment.



VPD Spring type / Side port / Push-in fitting / Standard holder

RoHS Compliant 🕱 Copper alloy free available 🛷 CAD (2D&3D)







Model code	Pad O.D.		В	L1	L2	E1	E2			Spring force	Connection
	ød	øD						С	S	(N)	config. code
VPD10-6F5-3J		3				18.6		10.9			
VPD10-6F5-4J9	1	4	61.5	38.4			18.5		6	4.0~7.1	
VPD10-6F5-6J9		6			20	19.9		11.7			
VPD10-10F5-3J		3				18.6		10.9			
VPD10-10F5-4J		4	66.5	43.4			25		10	2.0~5.2	
VPD10-10F5-6J	10	6				19.9		11.7			
VPD10-15F5-3J		3				18.6		10.9			
VPD10-15F5-4J		4	76.5	48.4	25	30	10.5	15	2.0~5.9		
VPD10-15F5-6J		6				19.9		11.7			
VPD10-20F5-3J		3				18.6		10.9			
VPD10-20F5-4J		4	92.5	55.4	34	10.0	37	10.5	20	1.1~4.8	
VPD10-20F5-6J		6				19.9		11.7			-M4
VPD15-6F5-3J		3				18.6		10.9			-1014
VPD15-6F5-4J9		4	61.5	38.4		10.0	18.5	10.5	6	4.0~7.1	
VPD15-6F5-6J9		6			20	19.9	1	11.7			
VPD15-10F5-3J		3			20	18.6		10.9			
VPD15-10F5-4J		4	66.5	43.4		10.0	25	10.9	10	2.0~5.2	
VPD15-10F5-6J	15	6				19.9		11.7			
VPD15-15F5-3J	15	3				18.6		10.9			
VPD15-15F5-4J		4	76.5	48.4	25	10.0	30	10.9	15	2.0~5.9	
VPD15-15F5-6J		6				19.9		11.7			
VPD15-20F5-3J		3				10.0		10.9			
VPD15-20F5-4J		4	92.5	55.4	34	18.6	37	10.9	.9 20	1.1~4.8	
VPD15-20F5-6J		6				19.9	1	11.7			


%.5: Replaced with Pad rubber material code. Refer to page 916 for details.

※ . 9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts). -S3 spec. is available for model codes with 9 in the table above.

% .Pad material N and NE are not suitable for use under ozone environment.

※.Tightening torque of a pad holder fixing bulkhead nut is as followings. Pad O.D. : ø10, ø15mm ▶ 8~10N·m. Pad O.D.. ø20~ø30mm ▶4.5~6N·m. VPD203F569 VPD253F569 VPD303F569





RoHS Compliant X Copper alloy free available M CAD (2D&3D)



Unit · mm	U	nit	:	mm
-----------	---	-----	---	----

										, c	///it • //////
Model code	Pad O.D. ød	Tube O.D. ØD			L2	E1	E2	Tube end C		Spring force (N)	Connection config. code
VPD20-6F5-3J		3				18.6		10.9			
VPD20-6F5-4J9		4	64.4	41.3		10.0	18.5	10.9	6	7.0~12.6	
VPD20-6F5-6J9		6			20	19.9		11.7			
VPD20-10F5-3J		3			20	18.6		10.9			
VPD20-10F5-4J		4	70.4	47.3		18.6	24.5	10.9	10	3.3~10.0	
VPD20-10F5-6J	20	6				19.9		11.7			
VPD20-15F5-3J	20	3				18.6		10.9		3.3~10.4	
VPD20-15F5-4J		4	80.4	52.3	25	10.0	29.5	10.9	15		
VPD20-15F5-6J		6				19.9		11.7			
VPD20-20F5-3J		3				18.6		10.9	20	2.0~8.7	
VPD20-20F5-4J		4	96.4	59.3	34	10.0	36.5	10.9			
VPD20-20F5-6J		6				19.9		11.7			-M6
VPD25-6F5-3J		3				18.6		10.9			-1010
VPD25-6F5-4J9		4	64.4	41.3		10.0	18.5	10.5	6	7.0~12.6	
VPD25-6F5-6J9		6			20	19.9		11.7			
VPD25-10F5-3J		3			20	18.6		10.9			
VPD25-10F5-4J		4	70.4	47.3		10.0	24.5	10.5	10	3.3~10.0	
VPD25-10F5-6J	25	6				19.9		11.7			
VPD25-15F5-3J	25	3				18.6		10.9			
VPD25-15F5-4J		4	80.4	52.3	25	10.0	29.5	10.5	15	3.3~10.4	
VPD25-15F5-6J		6				19.9		11.7			
VPD25-20F5-3J		3				18.6		10.9	0.9 20	2.0~8.7	
VPD25-20F5-4J		4	96.4	59.3	34	10.0	36.5	10.9			
VPD25-20F5-6J		6				19.9		11.7			



Unit:mm

Model code	Pad O.D. ød	Tube O.D. øD	В	L1	L2	E1	E2	Tube end C	Stroke S	Spring force (N)	Connection config. code
VPD30-6F5-3J		3				18.6		10.9			
VPD30-6F5-4J9		4	64.4	41.3		10.0	18.5	10.9	6	7.0~12.6	
VPD30-6F5-6J9		6			20	19.9		11.7			
VPD30-10F5-3J		3			20	18.6		10.9]
VPD30-10F5-4J		4	70.4	47.3		10.0	24.5	10.9	10	3.3~10.0	
VPD30-10F5-6J	30	6				19.9		11.7			-M6
VPD30-15F5-3J	30	3				10.0		10.0			
VPD30-15F5-4J		4	80.4	52.3	25	18.6	29.5	10.9	15	3.3~10.4	
VPD30-15F5-6J		6				19.9		11.7			
VPD30-20F5-3J	1	3				18.6		10.9			1
VPD30-20F5-4J	1	4	96.4	59.3	34	10.0	36.5	10.9	20	2.0~8.7	
VPD30-20F5-6J		6				19.9		11.7			

%. 5 : Replaced with Pad rubber material code. Refer to page 916 for details.


* .9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts). -S3 spec. is available for model codes with 9 in the table above.

%.Pad material N and NE are not suitable for use under ozone environment.

※.Tightening torque of a pad holder fixing bulkhead nut is as followings. Pad O.D.: ø10, ø15mm ▶8~10N·m. Pad O.D.: ø20~ø30mm ▶4.5~6N·m.

VPD Spring type / Side port / Barb fitting / Standard holder

RoHS Compliant 💥 Copper alloy free available 🚿 CAD (2D&3D)



Unit : mm

Model code	Pad O.D.	Tube I.D.	В	L1	L2	Е	Stroke	Spring force	Connection
would code		øD	D						config. code
VPD10-6F5-4B9		2.5	61.5	38.4		18.5	6	4.0~7.1	
VPD10-6F5-6B9		4	01.5	50.4	20	10.5	0	4.0 - 7.1	
VPD10-10F5-4B		2.5	66.5	43.4	20	25	10	2.0~5.2	
VPD10-10F5-6B	10	4	00.5			25	10	2.0 5.2	
VPD10-15F5-4B		2.5	76.5	48.4	25	30	15	2.0~5.9	
VPD10-15F5-6B		4	70.5	40.4	25	50	15	2.0 - 5.5	
VPD10-20F5-4B		2.5	92.5	55.4	34	37	20	1.1~4.8	
VPD10-20F5-6B		4	52.5	55.4	34	57	20	1.1 4.0	-M4
VPD15-6F5-4B9		2.5	61.5	38.4	20	18.5	6	4.0~7.1	-1114
VPD15-6F5-6B9		4	01.5	50.4		10.0		4.0 7.1	_
VPD15-10F5-4B		2.5	66.5	43.4		25	10	2.0~5.2	
VPD15-10F5-6B	15	4	00.5			25	10	2.0 5.2	
VPD15-15F5-4B	15	2.5	76.5	48.4	25	30	15	2.0~5.9	
VPD15-15F5-6B		4	10.5	+0.+	25		15	2.0 0.0	
VPD15-20F5-4B		2.5	92.5	55.4	34	37	20	1.1~4.8	
VPD15-20F5-6B		4	52.5	55.4		57	20	1.1 4.0	
VPD20-6F5-4B9		2.5	64.4	41.3		18.5	6	7.0~12.6	
VPD20-6F5-6B9		4	04.4	41.0	20	10.5	0	7.0 12.0	
VPD20-10F5-4B		2.5	70.4	47.3	20	24.5	10	3.3~10.0	
VPD20-10F5-6B	20	4	10.4	47.0		24.0	10	0.0 10.0	-M6
VPD20-15F5-4B		2.5	80.4	52.3	25	29.5	15	3.3~10.4	1410
VPD20-15F5-6B]	4	00.4	02.0		20.0	.5	0.0 10.4	
VPD20-20F5-4B		2.5	96.4	59.3	34	36.5	20	2.0~8.7	
VPD20-20F5-6B	1	4	00.4	00.0		00.0	20	2.0 0.7	

※.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

% .Pad material N and NE are not suitable for use under ozone environment.

※.Tightening torque of a pad holder fixing bulkhead nut is as followings. Pad O.D.: ø10, ø15mm ▶8~10N·m. Pad O.D.: ø20~ø30mm ▶4.5~6N·m.



Unit:mm

Model code	Pad O.D. ød	Tube I.D. øD	В	L1	L2	E	Stroke S	Spring force (N)	Connection config. code
VPD25-6F5-4B9		2.5	64.4	41.3		18.5	6	7.0~12.6	
VPD25-6F5-6B9		4	04.4	41.5	20	10.0	0	1.0 ~ 12.0	
VPD25-10F5-4B		2.5	70.4	47.3	20	24.5	10	3.3~10.0	
VPD25-10F5-6B	25	4	70.4	47.5		24.0	10	3.3.0 10.0	
VPD25-15F5-4B	25	2.5	80.4	52.3	25	29.5	15	3.3~10.4	
VPD25-15F5-6B		4	00.4	52.5	25				
VPD25-20F5-4B]	2.5	96.4	59.3	34	36.5	20	2.0~8.7	
VPD25-20F5-6B		4	90.4						-M6
VPD30-6F5-4B9		2.5	64.4	41.3		18.5	6	7.0~12.6	-1010
VPD30-6F5-6B9		4	04.4	41.5	20	18.5	0	1.0~12.0	
VPD30-10F5-4B		2.5	70.4	47.3	20	24.5	10	3.3~10.0	
VPD30-10F5-6B	30	4	70.4	47.5		24.5	10	5.5 - 10.0	
VPD30-15F5-4B	- 30	2.5	80.4	52.3	25	29.5	15	3.3~10.4	
VPD30-15F5-6B		4	00.4	52.5	25	29.5	15	5.5 - 10.4	
VPD30-20F5-4B		2.5	96.4	59.3	34	36.5	20	2.0~8.7	
VPD30-20F5-6B		4	50.4	39.3	54	50.5	20	2.0 00.7	

%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.


※ .9: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts). -S3 spec. is available for model codes with 9 in the table above.

% .Pad material N and NE are not suitable for use under ozone environment.

※.Tightening torque of a pad holder fixing bulkhead nut is as followings. Pad O.D.: ø10, ø15mm ▶8~10N·m. Pad O.D.: ø20~ø30mm ▶4.5~6N·m.

VPD Spring type / Side port / Female thread / Standard holder

RoHS Compliant X Copper alloy free available of CAD (2D&3D)



Unit : mm

Stroke (mm)


Model code	Pad O.D.	D. B L1 L2	10	Е	Stroke	Spring force	Connection	
		D		LZ				config. code
VPD10-6F5-M69		61.5	38.4	20	18.5	6	4.0~7.1	
VPD10-10F5-M6	10	66.5	43.4	20	25	10	2.0~5.2	
VPD10-15F5-M6	10	76.5	48.4	25	30	15	2.0~5.9	
VPD10-20F5-M6		92.5	55.4	34	37	20	1.1~4.8	-M4
VPD15-6F5-M69		61.5	38.4	20	18.5	6	4.0~7.1	-11/14
VPD15-10F5-M6	15	66.5	43.4	20	25	10	2.0~5.2	
VPD15-15F5-M6	15	76.5	48.4	25	30	15	2.0~5.9	
VPD15-20F5-M6		92.5	55.4	34	37	20	1.1~4.8	
VPD20-6F5-M69		64.4	41.3	20	18.5	6	7.0~12.6	
VPD20-10F5-M6	20	70.4	47.3	20	24.5	10	3.3~10.0	
VPD20-15F5-M6	20	80.4	52.3	25	29.5	15	3.3~10.4	
VPD20-20F5-M6		96.4	59.3	34	36.5	20	2.0~8.7	
VPD25-6F5-M69		64.4	41.3	20	18.5	6	4.0~7.1	
VPD25-10F5-M6	25	70.4	47.3	20	24.5	10	2.0~5.2	-M6
VPD25-15F5-M6	20	80.4	52.3	25	29.5	15	2.0~5.9	-1010
VPD25-20F5-M6		96.4	59.3	34	36.5	20	1.1~4.8	
VPD30-6F5-M69		64.4	41.3	20	18.5	6	7.0~12.6	
VPD30-10F5-M6	30	70.4	47.3	20	24.5	10	3.3~10.0	1
VPD30-15F5-M6	30	80.4	52.3	25	29.5	15	3.3~10.4	
VPD30-20F5-M6		96.4	59.3	34	36.5	20	2.0~8.7	

%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

%.Pad material N and NE are not suitable for use under ozone environment.

※.Tightening torque of a pad holder fixing bulkhead nut is as followings. Pad O.D.: ø10, ø15mm ▶8~10N·m. Pad O.D.: ø20~ø30mm ▶4.5~6N·m.





RoHS Compliant M CAD (2D&3D) VPOD203F56 M14×1 VPOD253F56 σ 2-Hex.17 Stroke (mm) VPOD303F56 20,30,40,50 ш ഗ ш Hex.14 ୍ବ 17 14.3 Hex.17 ød Unit : mm VPOD20-20F 5-4B 2.5 75.9 63.8 41 20 1.5~4.9 VPOD20-20F5-6B 4 VPOD20-30F5-4B 2.5 88.9 76.8 54 30 1.1~4.8 VPOD20-30F5-6B 4 20 VPOD20-40F 5-4B 2.5 101.9 89.8 67 40 $1.0 \sim 4.5$ VPOD20-40F5-6B 4 VPOD20-50F 5-4B 2.5 114.9 102.8 80 50 0.9~4.5 VPOD20-50F 5-6B 4 VPOD25-20F 5-4B 2.5 75.9 63.8 41 20 $1.5 \sim 4.9$ VPOD25-20F5-6B 4 VPOD25-30F5-4B 2.5 88.9 76.8 54 30 1.1~4.8 VPOD25-30F5-6B 4 -M6 25 VPOD25-40F5-4B 2.5 101.9 89.8 67 40 $1.0 \sim 4.5$ VPOD25-40F 5-6B 4 VPOD25-50F5-4B 2.5 114.9 102.8 80 50 0.9~4.5 VPOD25-50F 5-6B 4 VPOD30-20F 5-4B 2.5 75.9 63.8 41 20 1.5~4.9 VPOD30-20F 5-6B 4

VPOD Spring type / Side port / Barb fitting / No cover holder

4 *.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

2.5

4

2.5

4

2.5

30

88.9

101.9

114.9

76.8

89.8

102.8

54

67

80

30

40

50

1.1~4.8

1.0~4.5

 $0.9 \sim 4.5$

* .Tightening torque of a pad holder fixing bulkhead nut is 4.5~6N·m.

VPOD30-30F5-4B

VPOD30-30F5-6B


VPOD30-40F5-4B

VPOD30-40F 5-6B

VPOD30-50F5-4B

VPOD30-50F 5-6B





Model code	Pad O.D.	в			Stroke	Spring force	Connection
	ød					(N)	config. code
VPOD20-20F5-M6		75.9	63.8	41	20	1.5~4.9	
VPOD20-30F5-M6	20	88.9	76.8	54	30	1.1~4.8	
VPOD20-40F5-M6	20	101.9	89.8	67	40	1.0~4.5	
VPOD20-50F5-M6		114.9	102.8	80	50	0.9~4.5	
VPOD25-20F5-M6		75.9	63.8	41	20	1.5~4.9	
VPOD25-30F5-M6	25	88.9	76.8	54	30	1.1~4.8	-M6
VPOD25-40F5-M6	25	101.9	89.8	67	40	1.0~4.5	-1010
VPOD25-50F5-M6		114.9	102.8	80	50	0.9~4.5	
VPOD30-20F5-M6		75.9	63.8	41	20	1.5~4.9	
VPOD30-30F5-M6	30	88.9	76.8	54	30	1.1~4.8	
VPOD30-40F5-M6	30	101.9	89.8	67	40	1.0~4.5	
VPOD30-50F5-M6		114.9	102.8	80	50	0.9~4.5	


%.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

*. Tightening torque of a pad holder fixing bulkhead nut is 4.5~6N·m.

946

VPF Spring type / Direct mount / Metric thread / Standard holder

RoHS Compliant X Copper alloy free available M CAD (2D&3D)



Model code	Pad O.D. ød	Spring force (N)	Connection config. code
VPF10F59	10	7.9~15.0	-M4
VPF15F59	15	7.9~15.0	-1014
VPF20F59	20	7.9~15.0	
VPF25F59	25	7.9~15.0	-M6
VPF30F59	30	7.9~15.0	


*.5 : Replaced with Pad rubber material code. Refer to page 916 for details.

* . D: Replaced with "-S3" for -S3 spec. (Copper alloy free material for metal parts and FKM or HNBR for sealing parts).

* .Pad material N and NE are not suitable for use under ozone environment.

%. Tightening torque of a pad holder fixing bulkhead nut is 4.5~6N·m.






% The Fitting model code for option "-S3" is different from that of standard products. Contact us for details.

% Model code of Vacuum Pad Holder alone is following. Contact us for price.

Model designation (Example)




 □: Holder type, ③: Stroke(For spring type holder only. VPF holder is excluded.),

 ⑥: Port size · type, ⑨:-S3 spec.


A Vacuum Pad Series

Vacuum Pad Flat Series

Pad dia. : ø20, ø25, ø30mm







Vacuum Pad Series

Vacuum Pad Flat Series

Vacuum Pad

▲ Common Safety Instructions for Vacuum Pads

Before selecting or using PISCO products, read the following instructions. Read the detailed instructions for individual series.

A Warning

- 1. Take safety measures in advance where a dropping work-piece can cause danger.
- 2. Make sure to install a vacuum pad holder securely. Looseness may cause trouble.
- 3.Pay special attention to the work conveyance by screwed vacuum pads, accompanied by rotary movement. There is a possibility of troubles due to the looseness of screws from the rotary movement.
- 4. There is a possibility of troubles due to the leakage of vacuum system, clogging, vacuum pad abrasion, crack, deterioration, the galling of slider part in the holder and the looseness in joints. Carry out maintenance inspection periodically.
- 5.When a work-piece is conveyed by a vacuum pad, consider the acceleration, impacts and wind pressure. Otherwise, the work-piece may drop during conveyance.

▲ Caution

- 1. Thoroughly read and understand the theoretical suction force in this catalog before selecting diameter, Qty and suction place of vacuum pads. Select vacuum pads with enough margin in suction force.
- 2. The product incorporating NBR as seal rubber material has a risk of malfunction caused by ozone crack. Ozone exists in high concentrations in static elimination air, clean-room, and near the high-voltage motors, etc. As a countermeasure, material change from NBR to HNBR or FKM is necessary. Consult with Pisco for more information.
- 3. Select the material of vacuum pad in accordance with use environment and ease of use, referring to "Selecting Method".
- 4.Select the suitable pad shape (type) in accordance with a work-piece and its shape, referring to "Characteristics of Pad Material".
- 5.Select spring-holder type when work-pieces have different heights or are weak against an external force. Select the suitable holder type, referring to spring force and spring length in the catalog.
- 6.Since spring-holder type has a sliding action, minimize the transverse load. Otherwise, the life time of the holder can be reduced or malfunction of the holder can occur.
- 7.In replacing vacuum pads, check the structure of holders and pads in the catalog and tighten the hexagonalcolumn of the holder with a proper tool, referring to the following tightening torque.

- 5 5 1					
Vacuum pad holder	Standard	Mini			
Pad screw size (mm)	Tightening t	orque (N·m)			
M4×0.7	0.5 ~ 1.0	0.9 ~ 1.1			
M6×1	2~	· 2.7			
M10×1.5	5~7	-			
M20×2	9 ~ 10	-			

Table tightening torgue

8.In replacing the adapters of Soft / Soft Bellows Series, check the structure of holders, pad and adapters and tighten the hexagonal-column of the holder with a proper tool, referring to the following tightening torque.

• Table. tightening torque

Pad screw size (mm)	Tightening torque (N⋅m)
M4×0.7	0.7 ~ 0.8
M6×1	1.5 ~ 2.0



-	· · ·	•			• ·	
Vacuum pad holder		Standard			Mini	
Vacuum pad holder type	VPA	VPC, VPD, VPF, VPHC, VPHD, VPHDW	VPE	VPMA	VPMC, VPMD	VPME
Bulkhead nut size (mm)			Tightening t	orque (N·m)		
M3×0.5	—	—	0.7	—	_	0.7
M4×0.5	—	—	—	1 ~ 1.2		
M4×0.7	1 ~ 1.2	—	—	—	_	—
M5×0.5	1.5 ~ 2	—	—	1.5 ~ 2	_	—
M5×0.8	—	—	1 ~ 1.5	—	_	1 ~ 1.5
M6×0.75	2~3	—	—	2 ~	- 3	—
M8×0.75	2.5 ~ 3.5	1.8 ~ 2.4	—	2.5 ~	- 3.5	_
M8×1	—	1.8 ~ 2.4	—	—	—	—
M10×1	5~7	4.5 ~ 6	—	5~7	4~6	_
M12×1	12 ~ 14	8 ~ 10	—	—	_	—
M14×1	18 ~ 21	4.5 ~ 6	_	—	_	_
M16×1	18~21(※)	2~3	_	—	—	
M20×1	19 ~ 21	_	—	—	—	
M22×1	19~21(※)	16 ~ 20	—	—	—	
M24×2	40 ~ 50	_	—	—	—	
M30×2	—	42 ~ 54	—	_	_	—

9.In installing vacuum pad holders of general and small type with bulkhead, check the structure and tighten the hexagonal-column of the holder with a proper tool, referring to the following tightening torque.

*Values for Vacuum pad holder for Packaging bag series.

10.In replacing vacuum pad rubbers of Standard Series ø80, ø100mm, ø150mm, ø200mm and Bellows Series ø80mm, ø100mm, check the structure of holders and pads and tighten the hexagonal-column of the holder with a proper tool, referring to the following tightening torque.


Table. tightening torque

Pad screw size (mm)	Tightening torque (N·m)
M4×0.7	05.07
M5×0.8	0.5 ~ 0.7

11. Check the structure of vacuum pad in the catalog before replacing a filter element.

12.Refer to "Common Safety Instructions for Fittings" for handing fitting joint parts.

- 13.In installing spring-holder type, do not hold the shaft A with a spanner. In replacing vacuum pad, hold the hexagonal-column of the shaft with a spanner. If the keyway B is deformed, there is a possibility of malfunction.
- 14.Excessive tightening of a fixing nut may deform the bulkhead part and result in malfunction of the keyway.
- 15.As the nature of rubber, powdery component like additives may come out on the surface of a vacuum pad as time elapses.



Vacuum Pad

Vacuum Pad Selection Guide

Selection Guide 1 > Select the diameter of vacuum pad from the formula ① and chart of the theoretical suction force ②


The theoretical suction force is determined from pad area and vacuum level. Calculated value is for reference only, so carry out the evaluation under an actual operating condition. The theoretical suction force is calculated under a static condition. Obtain an enough margin, considering the weight of a work-piece and acceleration of lifting, pause and rotary movement. Enough room is needed in deciding a number of pads and arrangement position.


1) Calculation by formula

w =

- W : Suction force(N)
- C : Pad area(cm²)
- P ∶ Vacuum level -kPa
- f : Safety factor Horizontal lifting (refer to the right fig.) ▶ 1/4 Vertical lifting (refer to the right fig.) ▶ 1/8
- *1.Refer to the following chart for Sponge Series.(Internal diameter is used for calculation)
- *2.Refer to the following chart for Flat Series.(Pad grooves are used for calculation)
- *3.As for Bellows, Multi-Bellows, Soft, Soft Bellows and Ultrathin Series, their theoretical suction force may exceed the strength of pad itself, depending on the vacuum level. Carry out the evaluation under an actual operating condition.
- O Chart of the theoretical suction force <Add safety factor to values from the chart> –

Standard / Bellows / Multi-bellows / Soft / Soft bellows / Skidproof / Ultrathin / Mark-free (*)








Vacuum Pao






Vacuum Pad

Selection Guide 2 > Select a vacuum pad type according to a work-piece.

Please select suitable pads for your application from the following.



es



Vacuum pad

482

Selection Guide 2 > Select a vacuum pad material from an application...

<u>FIE</u>	ase sele	ect the suita	ple ma	tenai ir	om me	lable.									
Iter	n	Pad material	Nitrile rubber	NBR Suited for the food sanitation act. (Japan)	HNBR	Silicone rubber	Conductive Silicone rubber	Urethane rubber	Fluoro rubber	Fluorosilicone rubber	EPDM	Conductive Butadiene rubber (Low resistance type)	Conductive NBR (low resistance)	Chloroprene rubber (For Sponge type)	Silicone rubber (For Sponge Type)
		Material code	N, NH (*1)	G	HN	s	SE	U	F	FS	EP	E	NE	-	S
			Card	board	Cardboard	Semicor	nductors	Cardboard	Chemical	Taking out	Application	General	Semi-	Uneven	Uneven
			Plyv	vood	Plywood	Takin	ng out	Plywood	environment	molded	that	pars of	conductors	work-piece	work-piece
			Metal	l plate	Metal plate	molde	d parts	Metal plate	High temp.	parts	requires	semicon-			Food-
			Food-r	related	Food-related	Thin wo	rk-piece		work-		light- resistant or	ductors			related
			Other of	general	Other general	Food-r	related		pieces		ozoneproof				
Ap	plication			ork	work						In use				
					In use under						under the				
					a low ozone						moisture				
					concentration						containing				
					environment						atmosphere				
Pa	Pad color		Black	Gray	Black	Translucent	Black	Blue	Grav	Salmon	Black	Black	Black	Black	Salmon
Ċ		Standard	50°~80°	60°~70°	50°~70°	50°	60°	55°~70°	60°~70°	-	50°~70°	70°	60°~70°	_	-
		Bellows	50°	-	50°	50°	60°	55°	60°	-	50°	-	60°	-	-
		Multi-bellows	50°	50°	50°	50°	-	55°	50°	-	50°	-	60°	-	-
	Surface	Oval	40°~50°	-	50°	40°~50°	50°~60°	55° (*2)	50° (*2)	-	50°	70°	70°	-	-
	hardness	Soft	40°	-	-	40°	60°	-	-	40°	-	-	50°	-	-
	(Shore A)	Soft bellows	40°	-	50°	40°	-	55°	-	-	50°	-	60°	-	-
Ph		Skidproof	50°	-	-	50°	-	55°	60°	-	-	-	60°	-	-
ysic		Ultrathin	40°	-	-	40°	-	55°	50°	40°	-	-	60°	-	-
Physical Properties		Flat	60°	-	-	40°	40°	50°	50°	-	-	-	60°	-	-
rop	Highest ope			0°C	140°C	-	0°C	60°C	230°C	180°C	150°C	100°C	110°C	80°C	180°C
erti	Lowest oper			0°C	-30°C		0°C	-20°C	-10°C	-50°C	-40°C	-50°C	-30°C	-45°C	-40°C
es	Weathera			<u> </u>	0	0		0	0	0	O	0	\triangle	0	0
	Ozone-pro			×	0	0		O	O	O	0	×	×	0	0
	Acid-resis			<u>^</u>	\triangle	0		×	O	0	O	\triangle	\triangle	\triangle	0
	Alkaline-re		(0	-	0	×	×	O	O	0	0	O	0
	Oil	(Gasoline oil)		0	O		<u>^</u>	O	0	\triangle	×	×	O	×	\triangle
		(Benzene/toluene)		<u> </u>	×		<u> </u>	\triangle	0	\triangle	×	×	\triangle	\triangle	\triangle
	Volume re	sistance	-	-	-	-	Max. 10⁵Ω·cm	-	-	-	-	Max. 2000-cm	Max. 2000-cm	-	-

Please select the suitable material from the table.

Legend C 🗇 Eest

 \bigcirc : Suitable

riangle : Good

×∶NG

*1.Material code "NH" is only available for Skidproof Series.

*2.It does not apply to pad size: 4×30mm.

Note 1). The above "Physical Properties" shows the data of general synthetic rubbers.

Note 2). The highest / lowest operating temp. is for momentary usage. Carry out durability evaluation in case of continuous usage under the highest / lowest operating temp.

Vacuum Pad Series

Please select the suitable vacuum pad resin material from the table.

		••••	e canabie racaani paa i			
			Pad material	PEEK	POM	Conductive PEEK
Iter	~	Material Mark free series code Resin attachment for Bell series	Mark free series	К	М	KE
nei	11		Resin attachment for Bellows	-QK	014	OKE
		code	series	-QN	-QM	-QKE
				Manufacturing machine for General production line		Manufacturing machine for
Ap	plication			liquid crystal / semiconductor	Food-related machine	liquid crystal / semiconductor
	·				Packaging machine	Electronic components
Pa	Pad color			Natural (ivory)	White	Black
	Highest op	eratin	g temp.	250°C	95°C	250°C
P	Lowest ope	erating	g temp.	-50°C	-60°C	-50°C
Physical	Weatherab	ility	·	0	×	0
	Acid-resist	ance		0	×	0
Prop	Alkaline-resistance		ce	0	\triangle	0
Properties	Self-lubricity		·	0	O	0
ies	Abrasion-re	esista	nce	0	0	0
	Volume res	sistand	ce	-	-	10⁵~10⁰Ω·cm

Vacuum Pao

Legend C 💿 : Best

⊖ : Suitable

riangle : Good

X ∶NG


Note 1). The above "Physical Properties" shows the data of pad resin material only. The holder of Mark-free Series is not included.

Note 2). The above "Physical Properties" shows the data of resin attachment only. The pad rubber is not included.


Note 3). The above "Physical Properties" shows a general properties of resin materials and not a guaranteed value. Carry out the necessary evaluation under an actual operating condition.

Note 4). The highest / lowest operating temp. is for momentary usage. Carry out durability evaluation in case of continuous usage under the highest / lowest operating temp.

Note 5).Volume resistance is a representative value from the material manufacture, and not a guaranteed value.



To prevent dust from getting into the pad holder.




483



Reference Guide for Vacuum Pad


Impact on pad

Avoid an impact or a large force on a vacuum pad, when it is pressed against a work-piece. It may cause deformation, crack or abrasion at an early stage of use. Adjust the pad position so that the lip of pad touches lightly on a workpiece. Especially a small type of vacuum pad should be positioned precisely.




Large and wide flat plate work-piece

When lifting large size of glass board or circuit board, work-piece may bend by the lifting acceleration or the self-weight. Select a proper size of pad and positioning, considering an enough margin of suction force.



Soft work-piece

When soft work-pieces such as plastic bags, papers or thin boards are sucked, work-pieces can be deformed or shrunk by vacuum suction (Figure-1). Select smaller vacuum pads and reduce the vacuum pressure. Smaller vacuum pads are suitable for plastic bags and papers. When plastic / paper bags are opened by using vacuum pads, shift the center of two vacuum pads slightly in order to open them easily as Figure-2 shows.




Inclined work-piece

Select Free Holder for an inclined work-piece.


Porous or perforated work-piece

Since the suction of a porous work-piece causes a drop of suction force, select the proper specifications of vacuum system and secure a larger effective crosssection area of the piping. Selecting a small type of vacuum pad is one of solutions to reduce the air leakage.




Lifting work-piece, sucking the both side of it

Since all vacuum pad holders are designed for horizontal lifting, consider the strength of holders and pads.




Work-piece with different heights

Select Long Stroke holders for work-pieces having different heights, or piled-up work-pieces. Its stroke can absorb the difference in height.



Conveyance with rotary movement

When vacuum pad is fixed with a screw and has a rotary movement, the pad may drop due to the loosened screw. Pay special attention when the vacuum location of work-piece is off the center of work-piece gravity.



A Vacuum Pad Series


Vacuum Pad

Pad dia. list by pad type and material

Pa	ad material				N	: Nitrile rubb	er			
F	Pad type	General type	Standard Deep type	Small type	Bellows	Multi- Bellows	Soft	Soft bellows	Ultrathin	Flat
	ø0.7	Ochoral type	Deep type			Dellows		DCIIOWS		
	ø1			•						
	ø1.5									
	ø2									
	ø3									
	ø4						•			
	ø6						•	•		
п	ø8	•						•		
Pad	ø10	•			•	•	•			•
dia. (mm)	ø15	•								•
(m	ø20	•				•		•		•
m	ø25	•	•		•					
Ŭ	ø30	•	•			•	•			•
	ø40					•				
	ø50									
	ø60									
	ø80									
	ø100		•		•					
	ø150									
	ø200	•								

•: Available

Vacuum Pad







Vacuum pad

486

Pa	d material				U :	Urethane rul	ober			
	ad type		Standard		Bellows	Multi-	Soft bellows	Skidproof	Ultrathin	Flat
-	au type	General type	Deep type	Small type	Dellows	Bellows	Solt bellows	экіцріооі	Oluaulin	Fidt
	ø0.7									
	ø1			•						
	ø1.5			•						
	ø2									
ſ	ø3	•		•						
	ø4			•						
ſ	ø6	•			•		•			
_	ø8	•					•		•	
ad	ø10	•			•	•	•	•	•	•
di i	ø15	•	•		•				•	•
<u>,</u>	ø20	•	•		•	•	•	•	•	•
Pad dia. (mm)	ø25		•		•					•
	ø30	•	•		•	•		•		•
	ø40	•	•		•	•		•		
Ī	ø50	•	•		•	•		•		
	ø60		•		•					
	ø80	•	•		•					
	ø100		•							
	ø150	•								
	ø200									


•: Available

Pa	d material				F : Fluor	o rubber				G : NBR S	Suited for the for	ood sanitation	act. (Japan)
_	ad turns		Standard		Bellows	Multi-	Chidaraaf	I literathin	Flat		Standard		Multi-
F	ad type	General type	Deep type	Small type	Dellows	Bellows	Skidproof	Ultrathin	Fiat	General type	Deep type	Small type	Bellows
	ø0.7												
[ø1												
	ø1.5			•								•	
	ø2												
ĺ	ø3			•									
	ø4	•		•									
	ø6												
_	ø8												
Pad dia. (mm)	ø10	•			•	•	•		•				•
<u>a</u> .	ø15								•		•		
<u> </u>	ø20		•		•	•	•	•	•	•			•
mr	ø25								•				
\sim	ø30	•	•		•	•	•		•		•		•
	ø40												۲
	ø50	•				•							۲
	ø60	•	•		•								
	ø80				•								
	ø100	•			•								
	ø150	•											
	ø200												

•: Available

A Vacuum Pad Series

Vacuum Pad



: Available



Vacuum pad

488

Pad n	naterial			HN : I	INBR					EP : I	EPDM			FS : Fluoros	silicone rubber
Devi	1.4	:	Standard	4	Dellering	Multi-	Soft		Standard	ł	Bellows	Multi-	Soft	0.4	1.114
Pad	type	General type	Deep type	Small type	Bellows	Bellows	bellows	General type	Deep type	Small type	type	Bellows	bellows	Soft	Ultrathin
	ø0.7			•											
	ø1	•		•											
	ø1.5			•						•					
	ø2	•		•											
	ø3	٠		۲											
	ø4	•						•		•					
	ø6	•			•		•	•			•		•		
_	ø8	•									۲				
Pad dia. (mm)	ø10	•			•	•		•			•		•		•
d	ø15	•			•						•		•		
	ø20	۲			٠	۲			۲		۲		•		
	ø25	•	•						•		•				
~ 	ø30	•	•		•	•		•	•		•	•			
	ø40	•				•					•				
	ø50	•			•	•			•		•				
	ø60	•			•				•		•				
	ø80	•	•		•			•	•		•				
	ø100	•							•		•				
	ø150	•													
	ø200	•													
•	Availab	e													

Pad material		N Nitrile rubber	S Silicone rubber	U Urethane rubber	F Fluoro rubber	SE Conductive Silicone rubber	E Conductive Butadiene rubber (Low resistance type)	NE Conductive NBR (Low resistance type)	HN HNBR	EP EPDM
F	Pad type					Oval				
	2×4	•	•	•	•	•		•	•	•
Ì	3.5×7	•		•	•	•		•	•	•
Ĩ	4×10	•	•	•	•	•	•	•	•	•
ĺ	4×20	•	•	•	•	•	•	•	•	•
D.	4×30	•	•			•	•	•	•	•
Pad dia.	5×10	•	•	•	•	•	•	•	•	•
la	5×20	•	•	•	•	•	•	•	•	•
(mm)	5×30	•		•	•	•		•	•	•
E	6×10	•	•	•	•	•	•	•	•	•
ĺ	6×20	•	•	•	•	•	•	•	•	•
	6×30	•	•	•	•	•	•	•	•	•
	8×20									
	8×30	•							•	

•: Available


Pad material		K : PEEK	M : POM	KE : Conductive PEEK	Q2K : PEEK	Q2M : POM	Q2KE : Conductive PEEK	
Pad type			Mark free		Resin attachment for Bellows series			
Pa	ø10	•	•	•	•	•	•	
ă	ø15				•	•		
la	ø20	•	•	•	•	•	•	
Ξĺ	ø25				•	•	•	
<u>=</u> [ø30	•	•	•	•	•	•	

•: Available


A Vacuum Pad Series

Vacuum Pad





Construction (VPC holder : Spring type / Top port)



%1. a : Standard spec. b : "-S3" spec.

%2. SUS303 equivalent corrosivity

%3. Nut material differs depending on the bulkhead thread size. See below table for details.

Bulkhead thread size	Nut material			
(mm)	Nickel-plated brass	Trivalent chromate carbon steel		
M5×0.5	0	_		
M6×0.75	0	-		
M8×0.75	0	_		
M10×1	0	—		
M12×1	_	0		
M14×1	_	0		
M16×1	_	0		
M20×1	-	0		
M22×1	_	0		
M24×2	0	—		
M30×2	0	—		

A Safety Instructions

This safety instructions aims to prevent personal injury and damage to properties by requiring proper use of PISCO products.

Be certain to follow ISO 4414 and JIS B 8370.

ISO 4414 : Pneumatic fluid power...General rules and safety requirements for system and their components.

JIS B 8370 : General rules and safety requirements for systems and their components.

This safety instructions is classified into "Danger", "Warning" and "Caution" depending on the degree of danger or damages caused by improper use of PISCO products.

Danger Hazardous conditions. It can cause death or serious personal injury.
 Warning Hazardous conditions depending on usages. Improper use of PISCO products can cause death or serious personal injury.

Caution Hazardous conditions depending on usages. Improper use of PISCO products can cause personal injury or damages to properties.

\land Danger |

- 1.Do not use PISCO products for the following applications.
 - ①.Equipment used for maintaining / handling human life and body.
 - 2. Equipment used for moving / transporting human.
 - ③.Equipment specifically used for safety purposes.

🕂 Warning

1.Selection of pneumatic products

- ①.A user who is a pneumatic system designer or has sufficient experience and technical expertise should select pneumatic equipments.
- ② .Due to wide variety of operating conditions and applications for PISCO products, carry out the analysis and evaluation on PISCO products. The pneumatic system designer is solely responsible for assuring that the user's requirements are met and that the application presents no health or safety hazards. All designers are required to fully understand the specifications of PISCO products and constitute all systems based on the latest catalog or information, considering any malfunctions.

2.Usage environment

Do not use PISCO products under the following conditions.

- 1 .Beyond the specifications or conditions stated in the catalog, or the instructions.
- Use at outdoors
- ③.Excessive vibrations and impacts.
- ④.Exposure / adhere to corrosive gas, flammable gas, chemicals, seawater, water and vapor.



3.Handling of product

- Handle the pneumatic equipment with enough knowledge and experience. Mishandling of compressed air is dangerous. A person having enough knowledge and experiences should carry out assembly, operation, and maintenance of devices equipped with pneumatic equipments.
- (2).Do not operate machine / equipment or remove pneumatic equipment until safety is confirmed.
 - (1).Make sure that preventive measures against falling work-pieces or sudden movements of machine are completed before inspection or maintenance of these machine.
 - (2) .Make sure the above preventive measures are completed. A compressed air supply and the power supply to the machine must be off, and also the compressed air in the systems must be exhausted.
 - (3).Restart the machines with care after ensuring to take all preventive measures against sudden movements.
- ③.Do not disassemble or modify PISCO products, which affect the performance, function, and basic structure of the product.
- ④.Take safety measures such as providing a protection cover if there is a risk of causing damages or fire on machine / facilities by a fluid leakage.
- ⑤.Do not touch the release-ring of a push-in fitting when there is a working pressure. The lock may be released by the physical contact, and tube may fly out or slip out.
- 6 .Frequent switchover of compressed air may generate heat, and there is a risk of causing burn injury.
- ⑦ .Avoid any load on PISCO products, such as, a tensile strength, twisting and bending. Otherwise, there is a risk of causing damage to the products.
- ⑧.Do not use PISCO products for applications where threads or tubes swing / rotate. The product can be damaged in these applications.
- ⑨.Do not swing or rotate resin body of the products by force. It may damage to the products and cause a fluid leakage.
- ID not supply excessively dry air to products. It may cause malfunction due to a deterioration of rubber parts.
- 1. Do not wash or paint products with water or solvent. Solvent may damage a resin body, or painting may cause malfunction.
- 12. The product incorporating NBR as seal rubber or gasket material has a risk of malfunction caused by ozone crack. Ozone exists in high concentrations in static elimination air, clean-room, and near the high-voltage motors, etc. As a countermeasure, material change from NBR to HNBR or FKM is necessary. Consult with Pisco for more information.
- ID not stand on a product, or put anything on it. It may cause falls, personal injury or damage to the product.

Safety Instructions

Warranty

When the product produces a trouble, which is caused by our responsibility, we will carry out either one of the following measures immediately.

①.Free-of-charge replacement of same product

②.Free-of-charge repair of the product at our factory

Disclaimer

- 1.PISCO does not take any responsibility for any incidental or indirect loss, such as production line stop, interruption of business, loss of benefits, personal injury, etc., caused by any failure on use or application of PISCO products.
- 2.When a cause of the trouble/malfunction applies to any of the following items, it is excluded from the coverage of the above warranty.
 - ① .A case by a natural disaster, a fire except our responsibility, the act by the third person/party, the intention or fault of the customer.
 - ② A case when a product is used out of the specific range or in a method listed in the product catalog or the instruction manual.
 - ③ A case by the remodeling of the product or by a change of structure, performance, or specifications which PISCO does not involved in.
 - ④ A case by the event that is unpredictable by the evaluations and the measures at the time on or before the initial delivery.
 - (5). A case caused by the phenomenon that is able to be evaded if your machine or equipment has functions or structures that are comprised in a common sense when this product is incorporated in your machine or equipment.
- 3. The damages caused by the defect of Pisco products shall be covered but limited to the full amount of the PISCO products paid by the customer. Additionally, the above warranty is limited simply to the product itself. The damage induced by the trouble of the product will not be compensated.



Common Safety Instructions for Products in This catalog

\land Caution

1.An odd noise may be heard when supply pressures are immediately before the peak of vacuum levels. The sounding of this odd noise means the characteristics are unstable and the sound may become even noisier. This situation can also adversely affect the sensor, resulting in a malfunction or trouble. So reset the supply pressure.

% Pressure range in which odd noise occurs is affected by atmospheric pressure.

- 2.Piping design and equipment selection should be made with an effective sectional area on supply pressure side of a vacuum generator being 3 times as large as the nozzle diameter as a standard. Insufficient air flow may impair the performance of the product.
- 3.Do not use a lubricator on products.
- 4.Clean or replace silencer element periodically. There is a possibility of dropping the performance or causing troubles by clogging on the element.
- 5.Keep products away from water, oil drops or dusts because they are neither drip-proof nor dust-proof. Otherwise there is a possibility of causing malfunction, damage to the products, or dropping the performance.
- 6.Piping
 - Compressed air contains a volume of drain (water, oxidized oil, tar and foreign material, etc.) Because the drain reduce product performance remarkably, dehumidify air with an aftercooler and a dryer, and improve the air quality.
 - ②.Do not use a lubricator on products.
 - ③ .Rust in pipe and inflow of foreign substances cause the trouble, malfunction, and degradation of the product. Please install a filter (5µm or better filtration) in the compressed air supply line right in front of the product. The flushing inside the pipe before use and in certain intervals is recommended.
 - ④.Remove dusts or drain before piping. They may get into the peripheral machine / facilities and cause malfunction.
 - (5) When inserting an ultra-soft tube into push-in fitting, make sure to place an Insert Ring into the tube edge. There is a risk of causing the escape of tube and a fluid leakage without using an Insert Ring.
 - (6) Arrange piping avoiding any load on fittings and tubes such as twist, tensile, moment load, shaking and physical impact. These may cause damages to fittings, tube deformations, bursting and the escape of tubes.
 - ⑦.Install protective cover when using at a place getting the direct sunlight.
 - (8) .Be sure to confirm each port of a vacuum generator with its appearance drawing or the marking on it before piping. Incorrect piping has a risk of damaging the product.
 - ③ .Plumb a pressure sensor and a vacuum generator with pressure sensor at the end of vacuum system as much as possible. A long distance between a pressure sensor and a vacuum system end may increase plumbing resistance which may lead to a high vacuum level at the sensor even when no suctioning and a malfunction of pressure sensor. Make sure to evaluate the products in an actual system.
 - (10) A Shorter distance of plumbing with a wider bore is preferable at vacuum system side. A long plumbing with a small bore may result in slow response time at the time of releasing work-piece as well as in failure to secure adequate suction flow rate.


 In case of using non-PISCO brand tubes, make sure the tolerance of the outer tube diameter is within the limits of Table 1.


mm size	Nylon tube	Polyurethane tube	inch size	Nylon tube	Polyurethane tub
ø1.8mm	—	±0.05mm	ø1/8	±0.1mm	±0.15mm
ø2mm	—	±0.05mm	ø5/32	±0.1mm	±0.15mm
ø3mm	-	±0.15mm	ø3/16	±0.1mm	±0.15mm
ø4mm	±0.1mm	±0.15mm	ø1/4	±0.1mm	±0.15mm
ø6mm	±0.1mm	±0.15mm	ø5/16	±0.1mm	±0.15mm
ø8mm	±0.1mm	±0.15mm	ø3/8	±0.1mm	±0.15mm
ø10mm	±0.1mm	±0.15mm	ø1/2	±0.1mm	±0.15mm
ø12mm	±0.1mm	±0.15mm	ø5/8	±0.1mm	±0.15mm
ø16mm	±0.1mm	±0.15mm			

•Table 1. Tube O.D. Tolerance

7-1.Tube insertion (Push-in fitting)

- ①.Make sure that the cut end surface of the tube is at a right angle without a scratch on the tube surface or deformations.
- ②.When inserting a tube, the tube needs to be inserted fully into the push-in fitting until the tubing edge touches the tube end of the fitting as shown in the figure below. Otherwise, there is a risk of leakage.





Tube is not fully inserted up to tube end.

- ③ .After inserting the tube, make sure it is inserted properly and not to be disconnected by pulling it moderately.
 - When inserting tubes, Lock-claws may be hardly visible in the hole, observed from the front face of the release-ring. But it does not mean the tube will surely escape. Major causes of the tube escape are the followings; ① Shear drop of the lock-claws edge ② The problem of tube diameter (usually small)Therefore, follow the above instructions from ① to ③, even lock-claws is hardly visible.
- 7-2.Tube insertion (Compression fitting)
 - ①.Make sure that the cut end surface of the tube is at a right angle without deformations or a scratch on its inner and outer surface.
 - ② .Pass the tube through the nut and insert the barb into the tube up to the barb end. Then tighten the hexagonal-column of the nut with a proper tool.
 - ③.Refer to Table 2 which shows the tightening torque.
 - ※ Hold the tube when tightening the nut, since the tube may rotate along with the nut.



- ④.Make sure that the nut touches the metallic body. If not, loosen the nut, disconnect the tube and start over again from the process ①
- (5).Make sure that there is no leakage after tightening the nut.
- 6 .After inserting the tube, make sure it is inserted properly and not to be disconnected by pulling it moderately.

• Table 2. Nut tightening torque						
Tube O.D.	Tightening torque					
ø10	Max. 4N·m					
ø12	Max. 5N·m					
ø16	Max. 14N·m					

- 8-1.Tube disconnection (Push-in fitting)
 - ①.Make sure there is no air pressure inside of the tube, before disconnecting it.
 - ② Push the release-ring of the push-in fitting evenly and deep enough to pull out the tube toward oneself. By insufficient pushing of the release-ring, the tube may not be pulled out or damaged by scratch, and tube shavings may remain inside of the fitting, which may cause the leakage later.
- 8-2. Tube disconnection (Compression fitting)
 - ①.Make sure there is no air pressure inside of the tube, before disconnecting it.
 - ②.Use a proper tool to loosen the nut. Then disconnect the tube.
- 9.Installation of a fitting
 - When installing a fitting, use proper tools to tighten a hexagonal-column or an inner hexagonal socket. When inserting a hex key into the inner hexagonal socket of the fitting, be careful so that the tool does not touch lock-claws. The deformation of lockclaws may result in a poor performance of systems or an escape of the tube.
 - 2. Refer to Table 3 in the next page which shows the tightening torque, when tightening a thread. Do not exceed these limits to tighten a thread. Excessive tightening may break the thread part or deform the gasket to cause a fluid leakage. Tightening thread with tightening torque lower than these limits may cause a loosened thread or a fluid leakage. Since the sealability is affected by the processing condition of the installing part, adjust the tightening torque or correct the installing part, according to the condition.
 - ③.Adjust the tube direction while tightening thread within these limits, since some PISCO products are not rotatable after the installation.

Table 5. Tightening torque / Sealock Color / Gasket materials							
Thread type	Thread type Thread size Tightening torque		Sealock color	Gasket material			
	M3×0.5	0.7N∙m		SUS304+NBR SPCC+NBR			
	M5×0.8	1 ~ 1.5N·m					
	M6×1	2 ~ 2.7N∙m					
Metric thread	M3×0.5	0.7N∙m	n/a	РОМ			
	M5×0.8	1 ~ 1.5N·m					
	M6×0.75	0.8 ~ 1N·m					
	M8×0.75	1 ~ 2N·m					
	R1/8	4.5 ~ 6.5N·m		-			
Tonor nine thread	R1/4	7 ~ 9N∙m	White				
Taper pipe thread	R3/8	12.5 ~ 14.5N·m	vvnite				
	R1/2	20 ~ 22N·m					
Unified thread	No.10-32UNF	1 ~ 1.5N·m	n/a	SUS304+NBR, SPCC+NBR			
	1/16-27NPT	4.5 ~ 6.5N·m		-			
National Pipe	1/8-27NPT	4.5 ~ 6.5N·m					
Thread Taper (American	1/4-18NPT	7 ~ 9N∙m	White				
(American standard)	3/8-18NPT	12.5 ~ 14.5N·m					
olandara)	1/2-14NPT	20 ~ 22N·m					
	G1/4	12 ~ 14N·m		Aluminum + PBT			
G thread	G3/8	22 ~ 24N·m	n/a				
	G1/2	28 ~ 30N·m					

Table 3	Tightening	torque	/ Sealock color	/ Gasket materials
	nunterina	loruue		/ Gaskel malenais

% These values may differ for some products. Refer to each specification as well.

- ④.When removing a fitting, use proper tools to loosen a hexagonal-column. When inserting a hex key into the inner hexagonal socket of the fitting, be careful so that the tool does not touch lock-claws. The deformation of lock-claws may result in a poor performance of systems or an escape of the tube.
- ⑤.Remove the sealant stuck on the mating equipment. The remained sealant may get into the peripheral equipment and cause malfunctions.

10.Handling of PISCO products

- ①.Impact caused by dropping or the like may lead to damage to the product and a fluid leakage.
- 11.PISCO products shall be used within the Operating temp. range, including the heat of the product itself generated by adiabatic compression.